

# Summit™

The benchmark for on-wafer test and characterization

## Versatile microscope mounts

- High-stability or large-area
- Tilt back allows easy access to probes
- Manual, motorized or programmable

## Connection panels

- Coax, triaxial, and pin jack feed-troughs available
- Limit cable strain and motion for measurement stability
- Instrument stays connected to at back of panel
- Probe connection made at front of panel
- Simple to rearrange cabling when needed

## PureLine™ technology

- Enhanced EMI shielding
- Lowest spectral noise floor and system AC noise
- Ideal for low level and 1/f measurements

## AttoGuard®

- Extends instrument guard to completely surround wafer
- Makes the station invisible to the instrument
- Extremely low capacitance and leakage characteristics
- Fast settling times

## Rollout stage

- Full wafer access for safe and easy loading
- Maintains chuck integrity without contaminating layers
- Easy access to calibration substrates on auxiliary chucks

## MicroChamber®

- EMI shielding for low noise measurements
- Environmentally sealed for moisture-free, low-temperature measurements
- Low volume for the fastest purge
- Light tight to eliminate the need for a dark box

## MicroChamber access door

- Hardware interlock to protect user from hazardous chuck bias voltage
- Full width for easy access to wafers and cal substrates

## Platen lift

- Easy contact and separate function for probe cards and positioners
- Available micrometer adjustment to set probe card contact

## Compact footprint

- Suitable for bench top use to preserve lab space
- Optional vibration isolation table

© Copyright 2011 Cascade Microtech, Inc. All rights reserved. Cascade Microtech, AttoGuard, FemtoGuard and MicroChamber are registered trademarks and eVue, PureLine, Nucleus, Summit and TopHat are trademarks of Cascade Microtech, Inc. All other trademarks are the property of their respective owners.

Data subject to change without notice

Summit-PH-1112

www.cascademicrotech.com



## eVue™ digital imaging system

- Easy probe set-up and navigation
- Simultaneous display of up to three cameras and optical magnifications
- Widest field of view for easy navigation
- Highest optical magnification for precise probe alignment
- Live motion frame rate to avoid damage to probes or wafer
- Internal focus allows fast Z-profiles to maintain contact over temperature

## Nucleus™ prober control software

- Automatic wafer alignment
- Auto XYZ and theta correction for sub-micron stepping
- Automatic die size measurement tool
- Real-time wafer mapping
- Integrated eVue management
- Serial and IEEE remote communication support

## Ergonomic accessory mount

- Keyboard and microscope controls easily accessed
- Maintains an orderly workspace on platen and benchtop

## TopHat™

- Maintains MicroChamber integrity
- Allows full access to positioners and microscope at any temperature
- Allows adjustments without exposing chamber to external environment
- Maintains chuck temperature, thermal equilibrium, and mechanical stability during probe adjustments

## Modular chucks

- FemtoGuard® triaxial and coax versions available
- High-performance thermal and economical non-thermal options
- Wide range of temperature options from -60 °C to 300 °C and higher
- 200mm and 150mm versions

## Auxilliary chucks

- Two integrated mounts for calibration substrates
- Thermally isolated to prevent load drift over temperature
- Contact height can be set independently from wafer
- Microwave absorber options available

## Chuck vacuum control

- Independent zones for various wafer sizes, die and shards
- Separate controls for auxiliary chucks

## Manual mode stage control

- Intuitive manual controls
- Wafer can be removed in the event of a power outage

